

Installation manual

all packed in a box

screws for perforated boards

screwhead and repair finish

sanding paper

sponge

roller to apply liquid glue

liquid glue

Vogl Strip

spatula to fill up screwheads

